INSTALLATION INSTRUCTIONS

安裝說明

 Pierce the Shower-Tube through Flange, and spread the sealant or apply sealant tape on the threads of Shower-Tube before connect to Water-outlet and Showerhead. After installation, position the Flange against the wall as Fig. 1 shows.

取出法蘭蓋套入淋浴接管末端後,將淋浴接管末端的牙塗上牙管膠或止洩帶並鎖入 牆壁端的出水口鎖緊,再將淋浴接管另一端的牙塗上牙管膠或止洩帶並與花灑鎖緊, 最後將法蘭蓋推至牆壁端定位。如圖1。

2. Pierce the **Shower-Tube** through **Flange**, and spread the sealant or apply sealant tape on the threads of **Shower-Tube** before connect to **Water-outlet** and **Showerhead**. After installation, position the **Flange** against the ceiling and tighten the **Screw** to fix the **Flange** as Fig. 2 shows.

淋浴接管末端後,將淋浴接管末端的牙塗上牙管膠或止洩帶並鎖入天花板端的出水 口鎖緊,再將淋浴接管另一端的牙塗上牙管膠或止洩帶並與花灑鎖緊,最後將法蘭 蓋推至天花板端定位,再使用螺絲起子將螺絲鎖緊,固定法蘭蓋。如圖2。







¦PU69−04−STAC ^{IIII} MADE IN TAIWAN

www.justime.com