## **MOUNTING INSTRUCTIONS**

6865 安裝說明

6865 SERIES:

- 1.) Loosen the **Set Screw** and disassemble the components for installation. 用隨附的六角板手將埋頭螺絲鬆開, 使主體與底座分離.
- 2.) Use **Mounting Base** as template to locate appropriate drilling centers with pencil. 用底座爲樣板用鉛筆點繪出要鑽孔的位置.
- 3.) Drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**. 水泥牆在鑽孔後須使用隨附的塑膠塞.
- 4.) Attach **Mounting Base** to wall with **Wall Screws**. 將底座鎖在牆上,並確認已完全固定.
- 5.) Press the **Main Part** tightly over the center stem showing on **Mounting Base** and secure with **Hexagon Key**.

套上主體,再用六角板手將埋頭螺絲鎖緊,完成安裝程序.



JUSTIME 巧時代 ST SHENG TAI BRASSWARE CO., LTD.

210708

PU68-65-ST00 MADE IN TAIWAN