## **MOUNTING INSTRUCTIONS**

6899 安 裝 說 明

- **1.)** Loosen the **Set Screw** and disassemble the components for installation. 用隨附的六角板手將埋頭螺絲鬆開, 使不銹鋼主體與黑色底座分離.
- 2.) Use **Mounting Base** as template to locate appropriate drilling centers with pencil. 用黑色底座為樣板用鉛筆點繪出要鑽孔的位置.
- 3.) Drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**. 水泥牆在鑽孔後須使用隨附的塑膠塞.
- 4.) Attach **Mounting Base** to wall with **Wall Screws**. 將黑色底座鎖在牆上,並確認已完全固定.
- 5.) Press the **Main Part** tightly over the center stem showing on **Mounting Base** and secure with **Hexagon Key**.

套上不銹鋼主體,再用六角板手將埋頭螺絲鎖緊,完成安裝程序.



JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.

www.justime.com



100708

PU68-99-ST00

MADE IN TAIWAN