## INSTALLATION INSTRUCTIONS

6909安裝說明

1. Select proper position for product and mark center of mounting hole on wall. For double Bracket fixing, mark centers of mounting holes by using a spirit level and refer to the actual product for distance between hole centers. 請先選取預定安裝的位置,並在牆壁上畫上預定鑽孔記號,如果要安裝雙背板基座的產品,請先確認鑽孔的位置 是在同一水平線上,並以產品比對確認鑽孔的距離

2. Drill holes in your marked locations. When mounting on drywall, insert Plastic Anchors. Attach Bracket to wall with Screws.

水泥牆在鑽孔後使用隨附的塑膠塞,然後將底座鎖在牆上,並確認已完全固定

3. Use the Hex Key to lossen the Set Screw in the Main Body. Slide the Main Body over the Bracket and tighten Set Screw ensuring the orientation of the Main Body is correct. 用隨附六角扳手先鬆開本體下方的埋頭螺絲,使本體能順利套進固定基座後,再鎖緊下方的埋頭螺絲,完成安 裝程序



JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.

www.justime.com

PU69-09-ST00 003 220110 MADE IN TAIWAN

## INSTALLATION INSTRUCTIONS

6909安裝說明

1. Select proper position for product and mark center of mounting hole on wall. For double Bracket fixing, mark centers of mounting holes by using a spirit level and refer to the actual product for distance between hole centers.

請先選取預定安裝的位置,並在牆壁上畫上預定鑽孔記號,如果要安裝雙背板基座的產品,請先確認鑽孔的位置 是在同一水平線上,並以產品比對確認鑽孔的距離

2. Drill holes in your marked locations. When mounting on drywall, insert Plastic Anchors. Attach Bracket to wall with Screws.

水泥牆在鑽孔後使用隨附的塑膠塞,然後將底座鎖在牆上,並確認已完全固定。

 Use the Hex Key to lossen the Set Screw in the Main Body. Slide the Main Body over the Bracket and tighten Set Screw ensuring the orientation of the Main Body is correct. 用隨附六角扳手先鬆開本體下方的理頭螺絲,使本體能順利套進固定基座後,再鎖緊下方的埋頭螺絲,完成安 裝程序



6909 SERIES:



6909

www.justime.com

