INSTALLATION INSTRUCTIONS

7810安裝說明

- 1. Use **Bracket** as template to locate appropriate drilling centers with pencil. 使用固定鐵片和鉛筆在預定鑽孔的位置.畫上記號.
- Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert Plastic Anchors. 安裝水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞使之齊平於牆面.
- 3. Attach **Bracket** to wall with **Wall Screws**. 將固定鐵片以螺絲鎖在牆面上.
- 4. Locate the **Main Body** on the **Bracket** and use the **Hex Key** to secure with **Set Screw** .

固定鐵片掛上產品本體,用六角扳手由下方鎖緊埋頭螺絲,完成安裝程序.



JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.

www.justime.com

7810

www.justime.com

PU78-10-ST00 MADE IN TAIWAN

INSTALLATION INSTRUCTIONS

7810安裝說明

- 1. Use **Bracket** as template to locate appropriate drilling centers with pencil. 使用固定鐵片和鉛筆在預定鑽孔的位置.畫上記號.
- Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**. 安裝水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞使之齊平於牆面.
- 3. Attach **Bracket** to wall with **Wall Screws**, 將固定鐵片以螺絲鎖在牆面上.
- 4. Locate the **Main Body** on the **Bracket** and use the **Hex Key** to secure with **Set Screw**.

固定鐵片掛上產品本體,用六角扳手由下方鎖緊埋頭螺絲,完成安裝程序.



000 110809

PU78-10-ST00

MADE IN TAIWAN

